FULL TWO YEAR WARRANTY

Philips Electronics North America Corporation warrants each new Norelco Product, Model 3865XL (except cutters and combs), against defects in materials or workmanship for a period of two years from the date of purchase, and agrees to repair or replace any defective product without charge. **IMPORTANT:** This warranty does not cover damage resulting from accident, misuse or abuse, lack of reasonable care, the affixing of any attachment not provided with the product or loss of parts or subjecting the product to any but the specified voltage.* Use of unauthorized replacement parts will void this warranty

PHILIPS ELECTRONICS NORTH AMERICA CORPORATION WILL NOT PAY FOR WARRANTY SERVICE PERFORMED BY A NON-AUTHO-RIZED REPAIR SERVICE AND WILL NOT REIMBURSE THE CON-SUMER FOR DAMAGE RESULTING FROM WARRANTY SERVICE PERFORMED BY A NON-AUTHORIZED REPAIR SERVICE, NO RESPONSIBILITY IS ASSUMED FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES.

In order to obtain warranty service, simply take or ship the product postage prepaid to the nearest Authorized Norelco Service Location. It is suggested that for your protection you return shipments of product by insured mail, insurance prepaid. Damage occurring during shipment is not covered by this warranty.

NOTE: No other warranty, written or oral, is authorized by Philips Electronics North America Corporation.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusion and limitations may not apply to you.

Read enclosed instructions carefully.

Manufactured for: Norelco Consumer Products Company A Division of Philips Electronics North America Corporation 1010 Washington Blvd. Stamford, CT 06912-0015

MADE IN HOLLAND.



This symbol on the product's nameplate means it is listed by Underwriters' Laboratories. Inc.

Norelco, Lift and Cut, RAZORMATE and are Registered Trademarks of Philips Electronics North America Corporation.

is a Trademark of Philips Electronics North America Corporation.

PHILIPS and Philips Shield are Registered Trademark of Philips Electronics N.V.

© Philips Electronics North America Corporation 1997.





3865XL Rechargeable Razor With Double Action Shaving System



IMPORTANT SAFETY INSTRUCTIONS

When using an electric razor, basic precautions should always be followed, including the following: Read all instructions before using this appliance.

DANGER

To reduce the risk of electric shock:

- 1. Do not reach for a razor that has fallen into water. Unplug immediately.
- Do not use while bathing or in a shower.
- Do not place or store razor where it can fall or be pulled into a tub or sink. Do not place in or drop into water or other liquid.
- 4. Always unplug this razor from the electrical outlet immediately after using, except when razor is (re)charging.
- 5. Unplug this razor before cleaning.
- When discarding razor, unplug razor and remove rechargeable batteries. See enclosed sheet for instructions.

WARNING

To reduce the risk of burns, fire, electric shock, or injury to persons:

- Close supervision is necessary when this razor is used by, on, or near children or the disabled.
- Use this razor for its intended household use as described in this manual. Do not use attachments not recommended by Philips Electronics North America

- 3. Never operate this razor if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the razor to an Authorized Norelco Service Location for examination and repair.
- Keep the cord away from heated surfaces.
- Never drop or insert any object into any opening.
- Do not charge or plug in razor outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- 7. Do not use this razor with a damaged or broken comb, as facial injury may occur.
- Always attach plug to razor first, then to outlet. Be certain that plug is inserted firmly into razor up to mark indicated on plug. To disconnect, turn razor off, then remove plua from outlet.
- 9. To prevent possible damage to the cord, do not wrap cord around the razor.
- 10. Never put razor in direct sunlight or store in case at a temperature above 140°F.

SAVE THESE INSTRUCTIONS

IMPORTANT: Your razor contains NICKEL-CADMIUM RECHARGEABLE BATTERIES. See enclosed instruction sheet for battery disposal information.





All Manual State And Download


■ FOR ASSISTANCE

For assistance or the Authorized Norelco Service Location nearest you, call toll free:

1-800-243-3050

Authorized Service Location information is available 24 hours a day, 7 days a week.

FEATURES



How the Norelco Lift and Cut® Patented Shaving System Makes Close Comfortable:



Groove channels beard closer to cutting system



Lifter raises hair



Blade cuts hair which then drops below skin level

Download from Www.Somanuals.com. All Manuals Search And Download.

IMPORTANT

Invest a month for the shave of a lifetime!

The Norelco Double Action Razor with the patented Lift and Cut® System is unlike any other shaving system you've ever tried. So different, it can take your skin and beard a little time to adapt. But it's an investment worth making.

Use your new razor exclusively for 3 weeks to fully enjoy the closeness of a Norelco shave.*

At first you may not get as close a shave as you expect, or your face may even become slightly irritated. This is normal since your beard and skin will need time to adjust.

Invest a month and you'll soon experience the full joy of your new razor. That incredibly close, incredibly comfortable shave that is so uniquely Norelco.

*Stick with it! If you alternate shaving methods during the adjustment period, it may make it more difficult to adapt to the Norelco shaving system.

VOLTAGE

In North America, Central America and South America, the most common voltage is between 110V and 130V AC. When traveling to other countries, common voltage may range to 240V AC. Your new razor will automatically convert internally to work on 100V to 240V AC systems.

An adaptor plug may be necessary for cord usage in some foreign countries. It is suggested that you take all adaptor plugs with you when traveling overseas to ensure compatibility with most foreign outlet configurations. Norelco Travel Adaptor Plug Kit, model TP5, may be purchased at a store near you or at an Authorized Norelco Service Location.


1. CHARGE METER

The Charge Indicator Meter (Fig. 1) indicates the amount of charge remaining in rechargeable batteries. The highest number displayed on meter is the maximum percentage of capacity remaining ("40" means 40%) and will be visible for approximately 8 seconds when razor is turned on or off and then will disappear.

IMPORTANT: Before using, the razor must be charged for a full 4 hours if:

- Your are using it for the first time.
- Razor has not been used for at least a month.
- Entire meter is blank.

Block "40" indicates 40% cell capacity remaining



2A. TO (RE)CHARGE

- First time charging requires a full 4 hours. After the initial charge, recharging requires only 1/2-hour. A fully charged razor will give approximately 2 weeks of 3 minute shaves per day.
- Use only the cord provided.
 (Re) charge at temperatures between 40°F and 95°F. Charging at lower or higher temperatures adversely affects lifetime of batteries.
- Slide ON/OFF switch to OFF.
- Connect cord to razor. Plug into 100V to 240V AC outlet.
- 4. When (re)charging, block "20" may briefly light red. After approximately 3 minutes, block "20" will then turn green and blink. Your razor is sufficiently charged for one 3-5 minute cordless shave
- As razor continues to (re)charge, successive blocks "40", "60", "80" and "100" will briefly blink green and then light.
- green and then right.

 (Re)charging longer than required period of time will not harm razor. However, continuously charging razor will reduce life of batteries.

3. WHEN TO RECHARGE

- The highest number displayed on meter is the maximum percentage of capacity remaining ("40" means 40%).
- Charging blocks do not remain lit while shaving. They are only visible for approximately 8 seconds when razor is turned on or off, and then will disappear.
- When block "20" lights red and briefly blinks this indicates it is time to recharge your razor.

3A. 1/2-HOUR QUICK CHARGE

After initial 4 hour charge, your razor will take only 1/2-hour to (re)charge batteries to full capacity.

3B. FAST SIX-MINUTE QUICK CHARGE

- When batteries are totally depleted, recharging for 6 minutes gives enough energy for one 3-5 minute cordless shave.
- Recharge your razor until the red block "20" turns green. Your razor is then sufficiently charged for one 3-5 minute cordless shave.

4. CORD/CORDLESS SHAVING

CORD

- Connect cord provided to razor.
- 2. Plug into 100V to 240V AC outlet.
- Slide and depress ON/ OFF switch ON. Begin shaving.
- 4. Turn razor OFF and unplug.

IMPORTANT: It is not recommended that this razor be used exclusively as a corded razor. Continual use as a corded razor as well as continuously charging razor will reduce life of batteries.

NOTE: Razor does not recharge during corded shaving.

CORDLESS

- Charge according to directions. Unplug razor from outlet.
- 2. Slide and depress ON/ OFF switch ON. Begin shaving.

5. SHAVING

- 1. Remove Protective Razor Head Assembly Guard. Turn razor ON.
- Shave against the direction of beard growth using a quick, circular motion.
- Keep the skin taut using your fingers to stretch the skin so blades can lift and cut whiskers off (Fig. 2).
- (rig. 2).

 4. Easy does it. Gently press the razor to your skin so the floating heads can follow the contours of your face.
- 5. Turn razor OFF (and unplug if shaving with cord).

IMPORTANT: Clean razor head regularly following MAINTENANCE instructions



6. POP-OUT TRIMMER

- 1. Switch razor ON.
- 2. Push Trimmer Slide Switch up to pop out Trimmer.
- Hold Trimmer, as shown (Fig. 3), to exact hairline desired. Move Trimmer downward with gentle pressure.
- Close Trimmer by pushing Trimmer Slide Switch down.
- 5. Turn razor OFF (and unplug if shaving with cord).

7. TO CLEAN TRIMMER

- Switch razor OFF (and unplug if shaving with cord).
- 2. Push Trimmer Slide Switch up to pop out Trimmer.
- 3. Brush out Trimmer section using long bristles of brush.
- 4. Lubricate Trimmer teeth twice a year with Norelco Razor Lubricant, model AL80, or one drop mineral oil.
- 5. Push Trimmer Slide Switch down.

8. MAINTENANCE/ CLEANING INSTRUCTIONS

IMPORTANT

- Always switch razor OFF and remove plug from outlet before cleaning.
- Always store razor with Protective Plastic Head Guard on Razor Head Assembly.
- Never clean, remove or replace head assembly while motor is on.
- Do not apply pressure to combs. Do not touch razor heads with hard objects as this may dent or damage precisionmade slotted combs.
- Do not use razor if combs are damaged or broken.






8A.ONCE A WEEK


- 1. Clean Razor Head Assembly as shown (Fig. 4).
- 2. Lift Razor Head Assembly using thumb and index finger to remove from razor housing (Fig. 5).
- 3 Clean inside of Razor Head Assembly and Hair Chamber with long bristles of brush.
- 4. Press Razor Head Assembly back on razor housing.

8B.ONCE EVERY 4-8 WEEKS


IMPORTANT: Do NOT interchange the cutters and combs. They are a matched set and if interchanged may adversely affect shaving performance until cutters reseat themselves. Therefore, remove, clean, and replace each set individually.


- 1. Remove Razor Head Assembly (Fig. 5).
- 2. While holding Razor Head Assembly in one hand, press center wheel down while turning counterclockwise to release frame and lift out. Set frame aside (Fig. 6).
- 3. Ślidé one cutter/ comb. at a time, out of frame as shown (Fig. 7).
- 4. Cutter should be held as shown and brushed in an upward motion (Fig. 8). Clean inside of comb with long bristles of brush in a circular







- For consistently close and comfortable shaves, razor heads should be cleaned and lubricated every 4-8 weeks. Cleaning heads in a degreasing liquid (e.g. Norelco Razor Cleaner. RAZORMATE Electrosonic Cleaner or alcohol).
- Replace cutter into comb section. Slide cutting head back into frame making sure that flat rim of cutting head slides under 2 clamps on frame.





- 7. Repeat procedure for other two cutting heads.
- 8. Replace frame, with cutting heads in place, back Razor Head into Assembly. While pressing down, turn wheel clockwise to lock frame into place (Fig. 9).
- Press Razor Head Assembly back on razor housing.
- 10. Spread Norelco Razor Lubricant, model AL80, or one drop of mineral oil over floating heads with your finger.





9. HQ4 REPLACE-MENT HEADS AND RAZOR **ACCESSORIES**

Replacement Heads:

The self-sharpening rotary blades in your Norelco razor are precision-made to give closer shaves. When they finally do need replacing, specify only Norelco brand replacement cutters and combs, model HQ4.

DO NOT USE shaver sharpeners as this will damage your blades and lifters and will adversely affect the shaving performance

NOTE: It is recommended that you replace your razor heads once a year.

Razor Cleaners:

Norelco RAZORMATE Electrosonic Heads Cleaner, model ERC100.

Norelco Razor Cleaner. model RC1776

Norelco Razor Lubricant. model AL80.

Norelco Razor Accessories may be purchased at a store near you, an Authorized Norelco Service Location, or by using the handy order form enclosed.

10. IMPORTANT **BATTERY DISPOSAL INFORMATION**

When discarding your razor:

THIS NORELCO RAZOR CONTAINS NICKEL-CAD-MIUM RECHARGEABLE BATTERIES WHICH MUST BE RECYCLED OR DIS-POSED OF PROPERLY.

Refer to enclosed instruction sheet for directions on removing rechargeable batteries

CAUTION:

- Batteries should be removed by consumer only when razor is to be discarded.
- Make sure razor is unplugged before dismantlina for batterv removal.
- All servicing or batterv replacement should be performed by an Authorized Norelco Service Location only.

()Norelco®

60-Day Money-Back Guarantee

To enjoy the closest and most comfortable shave from your new Norelco Men's Razor, the razor should be used exclusively for 3-4 weeks. This allows your hair and skin enough time to adapt to the Norelco Shaving System. If, after that period of time, you are not fully satisfied with your Norelco Men's Razor, send the product back and we'll refund you the full purchase price.

The razor must be shipped prepaid by insured mail, insurance prepaid, and have the sales receipt, indicating purchase price and the date of purchase, enclosed. The razor must be postmarked no later than 60 days after the date of purchase. Norelco reserves the right to verify the purchase price of the razor and limit refunds not to exceed suggested retail price.

Send dated sales receipt, your complete name and address as indicated below, and the razor, prepaid to:

Norelco Consumer Products Company A Division of Philips Electronics North America Corporation P.O. Box 1116

Skokie, IL 60076

Please allow 4-6 weeks for delivery of check.
Please Print!
NAME:
ADDRESS:
CITY:
STATE: ZIP:
TELEPHONE NO.: () Area Code REASON FOR RETURNING:



Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com