

NEC Interactive Software (NP01SW)

Setup Guide

1. What is needed?
 - a. Mac (Mac OS X Snow Leopard or better) or PC (Windows XP, Vista or 7)
 - b. Apple iPad or iPad2
 - c. NEC projector - can be connected via VGA/HDMI/DisplayPort/RGBHV or via a wired/wireless network (projector must have this capability). See projector user manual for confirmation of connection types available.
 - d. Network - must create local network or placed on the internal company network
 - e. Computer needs Java installed to run the NEC Interactive Software dashboard
2. Hardware configuration
 - a. Connecting a Mac or PC to the network
 - i. Follow instructions based on the operating system you are using
 - b. Connecting the NEC projector to the network
 - i. Follow the instructions as outlined in your projector's user manual
3. Wireless setup of iPad
 - a. Turn on iPad
 - b. Touch the Settings icon
 - c. In the Settings screen, touch the Network arrow key
 - d. Touch the SSID name of the network to which you want to connect. If it is a secured wireless network, follow the instructions to enter the shared keys or password. If a public wireless network is available to which you want to connect, simply touch it to connect.
Note: The computer, projector and iPad must be on the same network for proper connection
4. Install Software
 - a. Installing NEC Interactive Software
 - i. Software is located on the supplied USB thumb drive
 - ii. For PC: Click on the file "NEC Interactive Desktop Setup 1.2.11.exe" and follow the prompts
 - iii. For Mac: Click on file "NEC Interactive Desktop 1.2.11.dmg" and follow the prompts
 - b. Installing NEC Image Express
 - i. Software is located on the supplied USB thumb drive
 - ii. For PC:
 1. XP: Click on the file "IEU20XP.exe" and follow the prompts
 2. Vista/7: Click on the file "IEU20Vista.exe" and follow the prompts
 - iii. For Mac:
 1. Intel: Click on the file "ieu2_Intel_1_2_6_110_dmg.zip" to unzip. Then click on the file "Image Express Utility 2 (Intel).dmg" and follow the prompts.
 2. Power PC: Click on the file "ieu2_PPC_1_2_6_110_dmg.zip" to unzip. Then click on the file "Image Express Utility 2.dmg" and follow the prompts.
5. Connecting to the NEC Interactive Desktop
 - a. Select the NEC Interactive Software icon on your computer's desktop
 - b. Right-click on the NEC Interactive Software icon in the system tray
 - i. Select Settings
 - ii. Set a password
 - iii. Select Register
 - iv. Enter License Key provided on sticker inside the software box cover
 - v. Enter email address
 - vi. Select Register Computer
 - vii. Select OK

6. Install Doceri Remote iPad application
 - a. Select iTunes on the computer desktop
 - i. Go to the iTunes Store
 - ii. Type in "Doceri Remote" in the Search text field
 - iii. Select Download and drag the Doceri App into your Library
 - iv. Sync the iPad with your computer
 - b. Select iTunes App Store on the iPad
 - i. Type in "Doceri Remote" in the Search text field
 - ii. Select Doceri Remote to install the Doceri Remote App
 - iii. Select Install App
 - iv. Enter iTunes Password
 - v. Select OK
7. Connecting to NEC Interactive Software via iPad
 - a. Select the Doceri icon on the iPad
 - b. Select Scan Network (only required the first time used or for new computer connections)
 - c. Select desired computer (based on IP address)
 - d. Enter Password previously assigned in Step 5.b.ii
 - e. The desktop image should now appear on the iPad
8. Controlling your NEC projector
 - a. Select the NEC Interactive Software icon on the computers desktop
 - b. Right click on the NEC Interactive Software icon in the system tray
 - i. Select Settings
 - ii. Select AV Control
 - iii. Enter the Projector IP Address in the Projector Address field (Projector IP address can be found in projector's On Screen Display)
 - iv. Select OK
9. Controlling a different NEC Interactive Software desktop
 - a. Select the Doceri icon on the iPad
 - b. Select Scan Network (only required the first time used or for new computer connections)
 - c. Select desired computer (based on IP address)
 - d. Enter Password previously assigned in Step 5.b.ii
 - e. The desktop image should now appear on the iPad
10. The USB thumb drive includes a video file with instructions on how to use the NEC Interactive Software with the Doceri App.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>