

Illustrated Parts List

Les Parties Illustrées Enumèrent

Las Partes Ilustradas Listan

20000 WATT

RESIDENTIAL GENERATOR


SYSTEM

Model / Modelo / Modèle

040265

Questions? Help is just a moment away!
Preguntas? La ayuda es justa un momento lejos!
Vous avez des questions? Vous n'avez pas besoin d'aller loin pour trouver de l'aide!
Call: Home Generator Helpline
Llamada: Línea Directa de Generador de Hogar
Appelez: Ligne Directe de Génératrice la Maison
(800) 975-8331 M-F 8-5 CT

UNIT EXPLODED VIEW



UNIT PARTS LIST

Item	Part #	Description
1	H203030GS	BASE, Mounting
2	187594GS	MOUNT, Vibration
3	24910GS	HHS, Trilobular 5/16 - 18 x 1/2
4	194683GS	SOLENOID, Gas Fuel
5	194829GS	FITTING, Coupling
6	194830GS	REGULATOR
7	195936GS	BRACKET, Mounting Solenoid
8	202382GS	FITTING, 3/4 Flare to 3/8 NPT
9	*	HHCS, M6 - 1.0 x 16
10	*	HHCS, M6 - 1.0 x 30
11	*	WASHER, 1/4 Lock
12	*	NUT, M6 - 1.0
13	B4300GS	HHS, Trilobular, 1/4 - 20 x 1/2
14	194818GS	BATTERY
15	185939UGS	WIRE-A, Black
16	198913GS	KIT, Battery Hardware
17	198593DGS	WIRE-A, Red
18	202958GS	TUBE, Air Cleaner
19	B4995GS	HHS, Trilobular, 1/4-20 x 7/8
20	*	WASHER, Flat 5/16 - M8
23	1723165SM	HOSE, Oil Drain
24	186649GS	DECAL, Oil Drain
25	*	HHCS, 5/16 - 18 x 2.5 Full Thread
26	*	NUT, 5/16 - 18
27	*	WASHER, Lock 5/16 - M8
28	186790CGS	WIRE
29	*	HHCS, 5/16 - 18 x 2"
30	*	HHCS, M12 - 1.75 x 35
31	*	WASHER, M12
32	B194685GS	SUPPORT, Engine/Alternator, Black
33	202922GS	SCREEN
34	*	WASHER, Shakeproof Ext. M6-1/4
35	185939WGS	WIRE, Ground
36	*	WASHER, 3/8 Lock
37	*	WASHER, Flat, 3/8 - M10
38	*	HHCS, 3/8 - 16 x 1
39	B198896GS	BRACKET, Mounting Alternator, Black
40	202761GS	DUCT, Air
41	*	SCREW, M5.8 x 10, Taptite
42	*	WASHER, Lock 3/8
43	*	SHCS, 3/8 - 16 x 1-1/4
44	*	HHCS, 5/16 - 18 x 3/4
45	B4300GS	HHS, Trilobular, 1/4 - 20 x 1/2
46	*	PPHMS, 4-40 x 0.19
47	*	WASHER, Lock #4

Item	Part #	Description
48	186205GS	SWITCH, Oil Temp
49	194699GS	PLATE, Switch Oil Temp
50	809743	SCREW
51	NSP	ASSY, Alternator (see page 7)
52	692062	SCREW
53	193506GS	DECAL, Caution Hot Surface
54	809872	GASKET
55	202885GS	MUFFLER
56	202884GS	BASE, Muffler Box
57	203533GS	KIT, Insulation, Muffler Box Base
58	56893GS	CRIMPTITE, 10 - 24 x 1/2
59	203087GS	ASSY, Bulkhead, Alternator End w/Seal
60	203534GS	KIT, Insulation, Muffler Box Top
61	194682GS	COLLECTOR, Muffler Box
62	202883GS	BOX, Muffler Top
63	192445GS	SCREW. 10 - 32 x 5/8
64	*	WASHER, M6 Shakeproof
70	205397GS	DECAL, Requirements, Fuel
900	§	ENGINE
901	842185	FUEL HOSE, with Clamp

Parts Not Illustrated

203003GS	MANUAL, Install
203002GS	MANUAL, Operator's
MS3483	MANUAL, Engine
203074GS	KIT, Manual/Accessory, HGS
B5478GS	PAINT, Touchup, HGS, Tan
B3518GS	CAP, Funnel Oil Bottle
202295GS	HOSE, Flex
198866GS	KIT, Led Remote
204017GS	KIT, Decals, Service


Optional Accessories

199473GS	PAINT, Touchup, Spray, Tan, 12oz
6030	KIT, Cold Weather (Includes Battery and Oil Warmers)

* - Items without part numbers are common fasteners and are available at your local hardware store.

§ - Contact Engine Manufacturer

ENCLOSURE EXPLODED VIEW




ENCLOSURE PARTS LIST

Item	Part #	Description	Item	Part #	Description
1	197275GS	PAD, Mounting w/ Holes	16	202956GS	SEAL, Foam, Engine Air
2	H203030GS	BASE, Mounting	17	192778GS	HHS, Trilobular, #8-32 x 1/2
3	203086GS	ASSY, Bulkhead, Engine End	18	195733GS	MOUNT, Tie Wrap
		. Bulkhead, Engine End	19	192940GS	RETAINER, Hose
		. Decal, Fuel Inlet	20	202957GS	SEAL, Foam, Alt Inlet
		. Seal, Foam	21	202916GS	ASSY, Roof/Siderails
		. Seal, Foam Engine Air			. Weldment Roof/Siderails
		. Bushing, 1-1/2			. Insulation
		. Bushing, 1-3/8	22	203087GS	ASSY, Bulkhead, Alternator End
		. Plug, Dome 1-1/2			. Decal, Caution Hot Muffler
		. Pin, Hinges with Hardware			. Seal, Foam
4	202914GS	ASSY, Door, Engine End			. Seal, Foam Alt Inlet
		. Weldment, Door Engine End			. Pin, Hinges with Hardware
		. Insulation			. Bracket, Muffler
		. Barrel, Hinges with Hardware	23	200409GS	DECAL, Caution Hot Muffler
5	198910GS	ASSY, Duct, Engine Air	24	203303GS	INSULATION, Engine Door, Bottom
		. Decals			ASSY, Vent, Exhaust
		. Lug, Ground Connect w/Hardware	25	198926GS	PLUG, Dome
		. Bracket, Mounting Breaker w/Hardware	26	198460GS	ASSY., Vent, Alternator
6	202919GS	ASSY, Support, Rail	27	198927GS	SEAL, Foam
		. Support Rail Eng. End	28	198888GS	COVER, Air Intake Engine
		. Seal, Foam	29	194694GS	INSULATION, Engine Door, Top
		. Decal, Rainproof	30	203302GS	SEAL, Foam
7	B4300GS	HHS, Trilobular, 1/4-20 x 1/2	31	197312GS	INSULATION, Front/Rear Door
8	203015GS	BUSHING, Snap, 2"	32	196397GS	INSULATION, Roof
9	197493GS	BUSHING, Snap, 1-1/2"	33	195597GS	KIT, Door, Hinge
10	198338GS	REGULATOR, VLTG	34	198890GS	SET, Latch Key
11	*	HHCS, 3/8 - 16 x 1	35	194828GS	KIT, Door Latch
12	*	WASHER, Flat, 3/8 - M10	36	198889GS	
13	*	WASHER, Lock 3/8			
14	*	NUT, 3/8 - 16			
15	202915GS	ASSY, Door			
		. Weldment Door			
		. Insulation			
		. Barrel Hinges with Hardware			
		. Decals			

* - Items without part numbers are common fasteners and are available at your local hardware store.

CONTROL PANEL EXPLODED VIEW & PARTS LIST



Item	Part #	Description
1	198911GS	ASSY, Cover, Circuit Breaker w/Decals
2	*	SCREW, 10 x 0.62, Plastite
3	202593GS	BREAKER, Circuit 100A, 2P
4	192770GS	BRACKET, Mounting Breaker
5	199011GS	LUG, Ground Connect
6	191991GS	BOLT, 1/4-10 x 1, Plastite
7	198573GS	FUSE, Auto Type 15 Amp
8	202118GS	ASSY, Control Panel
9	197492GS	SCREW, PT, M4 - 1.79 x 16.0
10	198910GS	ASSY, Duct, Engine Air w/Decals
12	198549GS	DECAL, Terminal Block
13	198550GS	DECAL, Ground, Neutral
14	205393GS	DECAL, Warning, Outdoor Install
15	193297GS	DECAL, Caution, Standby
16	205392GS	DECAL, Warning, Auto Start


Item	Part #	Description
17	205394GS	DECAL, Caution, Electric Shock
18	205395GS	DECAL, Warning Shock
19	*	NUT, 1/4 - 20
21	*	WASHER, Shakeproof, Ext M6 1/4
22	*	HHCS, 1/4 - 20 x 3/4

Parts Not Illustrated

202882GS	HARNESS, Wire, CTL Board to Engine/Alternator
198517GS	HARNESS, Wire, E1 & E2 Sensing
203020GS	HARNESS, AVR
198515GS	CONNECTOR, Terminal, 2 Pin
198516GS	CONNECTOR, Terminal, 10 Pin

* - Items without part numbers are common fasteners and are available at your local hardware store.

ALTERNATOR EXPLODED VIEW & PARTS LIST



Item	Part #	Description
1	195235GS	ADAPTER, Mounting, Alternator
2	199252GS	ASSY, Rotor
3	199254GS	STATOR
4	195234GS	RBC
5	197177GS	HEX HEAD, SEM Screw
6	66386GS	ASSY, Holder, Brush
7	66849GS	TAPTITE, M5 - 0.8 x 16
8	203200GS	WASHER, 3/8" SAE
9	200442GS	BOLT, 3/8 - 24 x 15.20"

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>