

STEEL SECURITY SAFE COFFRE-FORT DE SÉCURITÉ EN ACIER CAJA DE SEGURIDAD DE ACERO



The Honeywell trademark is used under license from Honeywell International inc. Honeywell International inc. makes no representations or warranties with respect to this product.

La marque déposée Honeywell est utilisée avec autorisation d'Honeywell International Inc. Honeywell international Inc. ne fait aucune affirmation et n'offre aucune garantie au sujet de ce produit.

La marca Honeywell se usa bajo licencia otorgada por Honeywell International Inc. Honeywell International Inc. no hace ningún tipo de representación ni garantía con respecto a este producto.

Read this manual carefully and never store it inside the safe!
Read this manual carefully and never store it inside the safe!
Read this manual carefully and never store it inside the safe!

Steel Security Safe with Digital Lock

PACKAGE CONTENTS


- 1 – Steel Security Safe
- 1 – Operation Manual
- 2 – Override Access Keys
- 4 – “AA” Batteries
- 1 – Mounting Kit w/ Bolts

DO NOT RETURN SAFE TO STORE!

If there are any missing parts or you have difficulty setting up or operating your safe, please contact our Consumer Assistance Department by telephone:

1-877-354-5457
(USA & Canada)
Monday–Friday
7am - 5pm PST

PRODUCT OVERVIEW




- A - LED Display panel
- B - Safe Cabinet Body
- C - Safe Door Assembly
- D - Electronic Digital Keypad
- E - Override Key Cover
- F - Serial Number Label

IMPORTANT: Remove plastic corners from outside of safe door before operating.

SETUP & OPERATION


STEP 1. OPEN SAFE WITH OVERRIDE KEY

1. Remove plastic override key cover.
2. Insert override key and turn right to unlock safe.
3. Open safe door (key can not be removed when open).



STEP 2. INSTALL BATTERIES

1. Remove battery compartment (A) cover on inside door.
2. Insert 4 “AA” batteries (included).
3. Replace the battery cover.
4. Do not close door before testing digital lock.



STEP 3. TEST DIGITAL LOCK

1. With door open, turn key left to put door bolts (B) in lock position.
2. Remove override key and store in a secure place. **Never store keys inside safe!**
3. Enter the factory preset pass code: “1”-“5”-“9”
4. Immediately after entering the code, press the “lock” key.
5. Lock bolts should recede into the unlocked position.

STEP 4. LOCK SAFE WITH A NEW PASS CODE


1. Close the safe door and hold it closed.
2. Enter a new (3-6 digit) pass code followed by “lock”.
3. Motorized lock will return door to closed position.
4. The LED will display “CLOSED” for 3 seconds followed by the active code entered as a reminder.



NOTE: The lock design allows for a new user code each time that the safe is locked

STEP 5. OPEN SAFE WITH NEW PASS CODE

1. To open safe enter the new pass code that was used to lock the safe followed by “lock”.
2. The motorized lock will unlock the door and the LED will display “OPENED”.



PRIVACY MODE:

To prevent the LED displaying the pass code entered, press “clear” prior to entering a code.


ENTERING THE WRONG CODE

If you press a wrong key while entering your code, you may press "clear" to reset prior to pressing, "lock". If you have entered the wrong code followed by "lock", the LED panel will display "ERROR"



SECURE LOCKOUT PERIOD

If a wrong code is entered 3 times in a row, the digital keypad will begin a five-minute lockout period. During this period the LED will display "HOLD05" and the keypad will become disabled. Once the lockout period has expired, the safe can be unlocked using the active code.



You may use the override key to open safe, but keypad complete the full lockout period.

OVERRIDE ACCESS KEY

If the active code is unavailable or your keypad fails due to dead batteries, etc., you may open the safe using the Override access key.

REPLACING BATTERIES

You may check the battery power at any time by pressing the "lock" key just once. The LED display will show one of the following messages:



Battery power is good



Battery power is low and batteries should be replaced

To replace the batteries please follow the instructions in STEP 2. in the SETUP section. It is NOT RECOMMENDED to use Non-alkaline or rechargeable batteries.

NOTE: The active code will not be erased if the batteries become weak or are removed.

IF YOU FORGET PASSCODE

1. Insert Override key and turn to right (open position).
2. With the key in the open position press "clear" on your keypad.
3. Turn the key to left (lock) position and remove it from lock.
4. The safe may be opened by pressing any 3-6 digit code followed by "lock".
5. You may now enter any new 3-6 digit code and return to normal operation.

SAFE SERIAL NUMBER

Whenever contacting our Consumer Assistance Department, you will need to provide the them with the serial number of your safe. The serial number tag is located on the lower right corner on the front of the safe.



IMPORTANT: Do Not Remove Tags! This is needed if your safe fails or you lose your keys.

ORDERING NEW KEYS

If a key is lost or you would like additional keys, contact our Consumer Assistance Department.

You will need to provide the following information:

- Safe Serial Number
- Number of keys requested
- Name / Address / Telephone
- E-mail address if available

To order by Mail, send above information with a check or money order for \$12.00 (U.S. funds) to:

Consumer Assistance Dept.
LH Licensed Products, Inc.,
860 East Sandhill Avenue,
Carson, CA 90746 USA

To order keys by telephone, call us toll-free at:

1-877-354-5457
(USA & Canada)
Monday-Friday
7am - 5pm PST

We do accept Visa and MasterCard payments for orders received by telephone.

Express Delivery available for additional charge. Subject to change without prior notification.

CONSUMER ASSISTANCE

Contact us by mail at the following address:

Consumer Assistance Dept.
LH Licensed Products, Inc.,
860 East Sandhill Avenue,
Carson, CA 90746 USA

Contact us by telephone (toll-free) at:

1-877-354-5457
(USA & Canada)
Monday-Friday
7am - 5pm PST

MOUNTING KIT

You may bolt your safe to the wall or floor to added theft protection and resistance to tipping. Your safe has pre-drilled bolt-down holes in the back panel and in the floor.

To secure your safe to the wall and/or floor:

1. Select a suitable and convenient location for your safe.
2. Empty the safe and remove the carpet
3. Locate the predrilled holes on the inside of safe
4. Place your safe in the desired location.
5. Line up the predrilled holes and mark the floor or wall through the holes.
NOTE: It is not recommended to attempt to bolt to both floor and wall.
6. Move the safe aside to clear marked spots for drilling.
7. Drill holes appropriate for hardware being used and the mounting surface
INCLUDED: (2 each – bolts, washers and masonry anchors).
8. Place the safe back over the holes and install the fasteners as required.
9. Once completed, replace the carpet.

NOTE: Bolting/unbolting of the unit is at the consumer's expense and discretion. LH Licensed Products is not responsible for any costs incurred if the unit is to be replaced

If you have questions about mounting the safe check with your local retailer or contractor.

REMOVABLE SHELF

Models 5103, 5104, 5107 & 5108

If your safe is equipped with a removable shelf, it can easily be removed to accommodate the storage of taller or larger items.

1. Empty shelf of all contents and remove any carpeting
2. Remove by lifting and tilting to side to fit through door opening.

DO NOT discard shelf. It is recommended that you for future needs.

LIMITED WARRANTY

LH Licensed Products, Inc., ("LHLP, Inc.") warrants that for a period of seven (7) years from the date of purchase, this product will be free from structural or mechanical defects resulting from materials or workmanship. LHLP, Inc., at its sole option and as the purchaser's sole remedy under this warranty, will repair or replace this product or any component of the product found to be defective during the warranty period. Replacement or repair will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. THIS IS YOUR EXCLUSIVE WARRANTY.

This warranty is only valid for the original retail purchaser from the date of initial retail purchase and is not transferable. You must keep the original sales receipt. Proof of purchase is required to obtain warranty performance.

LHLP, Inc. dealers, service centers, or retail stores selling this product do not have the right to alter, modify or in any way change the terms and conditions of this warranty.

This warranty does not apply to the finish on the product. This warranty does not cover normal wear and tear of parts or damage resulting from any of the following: negligent use or misuse of the product, use contrary to the operating instructions, disassembly, repair or alteration by anyone other than LHLP, Inc. or an authorized service center, improper installation, or exposure to extremes of heat or humidity. Further, the warranty does not cover Acts of God, such as fire, flood, hurricanes and tornadoes.

LHLP, Inc. shall not be liable for any incidental or consequential damages caused by the breach of any express or implied warranty or otherwise relating to the sale of this product. LHLP, Inc. is also not responsible for: costs associated with removing or installing the product; damage or loss of the contents of the product; nor for the unauthorized removal of the contents; or damages incurred during shipment.

THE ABOVE WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, AND LHLP, INC. DISCLAIMS ANY AND ALL OTHER COVENANTS AND WARRANTIES.

Except to the extent prohibited by applicable law, any implied warranty of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty period. Some states, provinces or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state, or province to province, or jurisdiction to jurisdiction.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>